

Instructions for Cable & Audio Clubhouse

Control Panel is on Wall / Pool Side

NO REMOTES NEEDED

1. Touch Screen – Options below
2. **Touch Cable** and TV will Turn on (turn channels here) Use arrows on Touch Screen (< >) to choose channel changing options.
3. **Touch Aux In**. Plug and Play from Phone or other audio device. Plug is near Men's Room Entrance. Check Volume on Phone. Control volume from Keypad.

TURNING OFF SYSTEM – 2 simple steps

1. Push Power on Keypad
2. Push Indoor Power off Button on touch screen
3. **USING HDMI Cable to project to TV**

Prior Approval is required. HDMI cable is connected and can be found behind TV (right side facing TV). Using remote change Source to HDMI and control volume. Turn System volume down on keypad it is only volume on TV no speakers. Remote will be on Mantle and should remain there.

5. This is a SMART TV and apps loaded on TV can be logged into with your info. (ie. YouTube for video slideshows)

YOU WILL FORFEIT deposit if HDMI is removed from TV or other cables compromised.

6. Please plan ahead on A/V use and if you have a questions please email before event.